Sliding Door Measuring & Ordering Guide

For Korniche and Origin aluminium sliding doors

Measure the opening in three places each way and take the **smallest**. Allow a fitting gap, typically **10mm off the width and height**, and give us both sizes.

How to Measure

1	Measure the width at the top, middle and bottom, brick to brick.
2	Measure the height on the left, middle and right, from the finished floor or base to the lintel.
3	Check the base is level and solid. Sliding panels are heavy and need a level, well-supported track.
4	Choose the panels and track: 2 panels on a double track open about half the width; 3 panels on a triple track open about two-thirds.
5	Say which panels slide and which are fixed, viewed from outside.
6	Plan the delivery and fitting crew. Large panels can weigh over 100kg each.

Your Measurements

Opening	Width top	Width mid	Width bottom	Height L	Height mid	Height R

Before You Order

- [ ] Smallest width and height recorded, plus the order size
- [ ] Number of panels, double or triple track
- [ ] Which panels slide, viewed from outside
- [ ] Frame colours and handle finish
- [ ] Glass: double or triple, laminated if needed
- [ ] Enough people or lifting gear for delivery and fitting

How Ordering Works

1	Use the supply form on the product page, or log in to the trade portal if you have a trade account.
2	We check your sizes and specification and send a written quote (trade accounts get their trade price).
3	Approve the drawing or order confirmation. **Check every size, colour, handing and glass type.** Once it is in production it cannot be changed.
4	Pay the proforma invoice. We place the order and confirm the delivery or collection date.
5	Check everything on arrival and report any damage or shortage within 48 hours, with photos.

Not sure? Send photos and rough sizes with your enquiry and we will check before anything is made. Call 0118 995 2549 or email cwgwindowcraig@gmail.com.